


Wi-Fi Node with Enclosure Installation



Wi-Fi sensor Connections

- **1. (Port A/ 18-24v POE)** can be used to power the Wi-Fi sensor using POE injector A.
- **2. (Port B/ 802.3af/ POE)** can be used to power the Wi-Fi sensor using a POE switch.



OPEN-MESH

Ceiling Case

- 100% tool free
- Fits 9/16" and 15/16" drop ceiling rails
- Mount on any solid wall or ceiling surface



Drop Ceiling Rails




Ceiling Mount Attachment







Wi-Fi Node Internal Communications Test



- Connect from Your Laptop ethernet port directly to the Wireless Router Ethernet Port #1
- Connect from Wireless Router port #2 directly to port #1 of the Anvision Poe Smart Switch
- Connect from Poe Smart Switch port #2-8 directly to the Wi-Fi sensor port B (802.3af POE)
- Open Browser and type in http://www.routerlogin.net \
- Username: admin / Password: password
- Open Attached Devices Tab and view the unknown devices.
- Confirm each Wi-Fi sensor is connected. (provide screenshot) send to tech support team.

